


- Onderdelen -
- Spare parts -
- Pièces de rechange -
- Ersatzteile -



Y422500

Pos.	Art.no.	Description	Pos.	Art.no.	Description
1	Y422500-1	Retaining ring	21	Y422500-21	Power unit assy
2	Y422500-2	Washer	22	Y422500-22	Spring
3	Y422500-3	Wheel	23	Y422500-23	Inspection plate
4	Y422500-4	Side plate assy	24	Y422500-24	Retaining ring
5	Y422500-5	Washer 16	25	Y422500-25	Shaft arm
6	Y422500-6	Hex nut M16	26	Y422500-26	Bolt
7	Y422500-7	Caster assembly	27	Y422500-27	Retaining ring
8	Y422500-8	Hex bolt M12x20	28	Y422500-28	Long linkage
9	Y422500-9	Spring washer	29	Y422500-29	Retaining ring
10	Y422500-10	Bolt	30	Y422500-30	Linkage axle
11	Y422500-11	Spring washer	31	Y422500-31	Lift arm assembly
12	Y422500-12	Nut M16	32	Y422500-32	Saddle
13	Y422500-13	Spring washer	33	Y422500-33	Separating sleeve
14	Y422500-14	Screw	34	Y422500-34	Rubber saddle pad
15	Y422500-15	Torsion spring	35	Y422500-35	Handle bumper
16	Y422500-16	Handle socket			
17	Y422500-17	Bolt	FW	Y422500-FW	Front wheel kit
18	Y422500-18	Handle upper	RK	Y422500-RK	Repair kit
19	Y422500-19	Hex bolt M6x35	RW	Y422500-RW	Rear wheel kit
20	Y422500-20	Handle lower			